

## Installation guide


# Absorgel Pouches



1 Open the transparent sealed outer plastic and take out the required quantity of Absorgel Pouch desiccants. This will activate the desiccants.



2 Place the desiccants with your products to be protected in the needed space as soon as possible, preferably within 10 minutes. Because the amount of moisture the desiccant can absorb will decrease the longer it is exposed to open air before being placed in the package.



4 Once the Absorgel Pouches are positioned, seal the package where the desiccant is used as soon as possible.



5 If any Absorgel Pouches are remaining in the original package, seal the bag as soon as possible to increase the shelf life of the desiccants.